USCCE

UE188 User Manual




18 Months Warranty After-sales mailbox:


support@uscceshop.com

Thank you for purchasing USCCE! Please read these instructions carefully before use and retain for future reference.


FRONT VIEW




LEFT SIDE VIEW



RIGHT SIDE VIEW



BACK VIEW




GETTING STARTED

Plug in the adapter into a standard household outlet to get the clock working.

Insert 2 "AAA" batteries(Not Included) to preserve the ALARM and TIME settings in case of power interruption.

TIME SETTING

1.Press **TIME SET**, the time will flash. Rotate " \nearrow " to adjust HOUR, and rotate " \nwarrow " to adjust MINUTE.



2. Press TIME SET again to confirm and exit from Time Setting Mode.

NOTICE: If digits continue flashing for 10s without any operation, the setting mode will be exited automatically.

SWITCH TIME FORMAT (12/24HR)

Press **12/24HR** to toggle between 12 and 24 hour mode (the default is 12-hour time format).

Notice: When using the 12-hour time format, AM/PM icon will appear to suggest morning/afternoon time.

ALARM ON/OFF

Press **ALARM 1 SET**, if time appears in TIME ZONE of " **1**", alarm is on. If "OFF" appeared in the time zone of " **1**", alarm shuts off permanently.





ALARM.1.2 SETTING

(ALARM 1 and ALARM 2 are set in the same way)

1.Press and hold **ALARM 1 SET** for 3 seconds, the alarm 1 time will flash. Rotate "♥" to adjust ALARM 1 HOUR, and rotate "♥" to adjust ALARM 1 MINUTE.



2.Press ALARM 1 SET to confirm and exit from Alarm 1 Setting Mode.

Notice: Press **VOLUME** repeatedly to adjust the alarm volume, 1-7 level adjustable. Volume value will appear when you are adjusting volume. Once the alarm volume is confirmed, this will apply to both alarms.

TO SELECT WAKE UP MODE

To select the wake up mode, slide **ALARM MODE SWITCH** to your desired position:

- a) "SOUND" for sound only
- b) "VIBRATION" for bed shaker
- c) "BOTH" for sound and bed shaker.

Notice: Once the wake up mode is chosen, this will apply to both alarms.

ALARM SOUND SET UP

- 1. Press **ALARM SOUND**, the alarm sound options will flash and the alarm sound will ring. Press **ALARM SOUND** repeatedly to choose among three alarm sound options:
- 01=Buzzer; 02=Siren; 03=Bird Sound.
- 2.If the alarm sound options, for example "02" flashes for more than five seconds, the alarm sound "02" will be confirmed automatically and exit from Alarm Sound Set-up Mode.

Notice: 1.Press any button except **ALARM SOUND** to confirm your alarm sound quickly. 2.Once the alarm sound is chosen, this will apply to both alarms.

BED SHAKER/ VIBRATOR

- 1. Attach the bed shaker jack to the back of clock at VIBRATOR INPUT.
- 2. Slide **ALARM MODE SWITCH** to "VIBRATION" or "BOTH" position.
- 3. Slide vibration intensity to desired position:
 - a) "HI" for HIGH SHAKE
 - b) "MED" for MEDIUM SHAKE
 - c) "LO" for LOW SHAKE.
- 4. Place vibrator between mattress and box spring.

SNOOZE/ TURN OFF ALARM DAILY

- 1. When the alarm goes off, press **SNOOZE** to snooze for a while, the alarm will go off again 9 minutes later.
- 2. To cancel the snooze at any time or to TURN OFF this day alarm while it is sounding/ vibrating, press any of the six buttons in the side. The alarm will go off again at the same time the next day.

BRIGHTNESS CONTROL

In standby mode, slide any of "\$\sigma\sig

USB CHARGING PORT

Connect to charge your cellphone or other smart device. Charging range: 5V/1A

WARRANTY

We offer a 45 day money-back guarantee and 18-month free replacement.

SUPPORT

If you encounter any problems with this clock then contact

support@uscceshop.com

where we will deal with your issue within 24 hours.